

2 3/4" ID Plastic Grommets

Instructions

1. The grommet body should be put on your worktable with the teeth facing up.
2. Place the washer on top with teeth facing down.
3. Lay a flat piece of wood on the top of the grommet washer, and strike the flat piece of wood (with a 4 lb. hand sledge hammer) to put the grommet together.
4. Do not strike the grommet directly with the hammer.

